



Mouse Pads and FuzziMats™ Transferring Instructions

Supplies Needed

- Spray Adhesive (optional)
- Sublimation Transfer
- Blank FuzziMat™ or Mouse Pad

Step 1: Adjust Heat Press

Heat Press Temperature: **400° F**
Dwell Time: **35-40 seconds**
Pressure: **Firm**

Note: These instructions, including transfer times and temperatures, are based on the inks, paper, equipment and supplies we use. Your inks, papers, etc. may require adjustments in your time/temp settings.

Step 2: Design Your Transfer

Design your transfer so that it is larger than the item (approx .125" larger), or print using registration marks to line-up the image.

Step 3: Prepare Your Transfer

1. Lightly spray the transfer with spray adhesive.
2. Place the transfer face up on a table.
3. Place the Mouse Pad or FuzziMat™ face-down on the transfer in appropriate position.
4. Turn the transfer and pad over together, and place them on the heat platen so the transfer is facing up.
5. Using **Firm** pressure, press at **400° F** for **35-40 seconds**.
6. Remove from press and peel transfer.

Customer Support

For support on these or any of our products, please call our toll-free number for assistance: **877.795.1500**. You may also write to us at Support@LaserReproductions.com.