



HOLIDAY ORNAMENT INSTRUCTIONS

Read These Instructions **COMPLETELY** before you begin.

Supplies Needed

- Blank Holiday Ornament
- Ornament Template (Comes on a CD with Ornaments)
- Sublimation Ink Transfer
- Heat **Conductive** Thermal Mat
- Heat **Resistant** Felt Pad

One Sided Printing

- 1) Open the template in either CorelDraw or Photoshop.
- 2) Paste your image beneath the template and size the image to fit the print area. Do not change the size of the template.
- 3) Place the 'Heat **Resistant** Felt Pad' in the center of your heat press.
- 4) Place your transfer **face up** in the center of your heat press.
- 5) Place your ornament on top of the transfer.
- 6) Place a blank sheet of paper on top of the ornament to prevent the possibility of anything transferring off of the mat.
- 7) Place the 'Heat **Conductive** Thermal Mat' on top of the paper.
- 8) Close the heat press with **light to medium** pressure. The ornaments are fragile and will break if care is not used.
- 9) Heat at **400** degrees for **3.5 to 4** minutes.
- 10) Open the press, remove the product, peel away the transfer. **CAREFUL** handling the ornament, it will be very hot. We recommend using heat resistant gloves.

Note: These instructions, including transfer times and temperatures, are based on using ArTainium™ sublimation inks, EZ Trans™ paper, and products as described. Other inks, papers, etc. may require adjustments in your time/temp settings.

Two Sided Printing

- 1) Open the template in either CorelDraw or Photoshop.
- 2) Paste your images beneath the templates and size the images to fit the print area. Do not change the size **or position** of the templates.
- 3) Print out the transfer on **8.5x11** paper.
- 4) Carefully fold the transfer in half so that the transfers line up with each other. Crease the paper and unfold the transfer.

- 5) Place the 'Heat **Resistant** Felt Pad' in the center of your heat press.
- 6) Place your transfer **face up** in your heat press with one of the templates centered.
- 7) Place your ornament on top of the centered template.
- 8) Fold the transfer closed and run your finger across the crease so that it lays flat.
- 9) Place the 'Heat **Conductive** Thermal Mat' on top of the paper.
- 10) Close the heat press with **light to medium** pressure. The ornaments are fragile and will break if care is not used.
- 11) Heat at **400** degrees for **3.5 to 4** minutes.
- 12) Open the press, remove the product, peel away the transfer. **CAREFUL** handling the ornament, it will be very hot. We recommend using heat resistant gloves.

Note: *These instructions, including transfer times and temperatures, are based on using ArTainium™ sublimation inks, EZ Trans™ paper, and products as described. Other inks, papers, etc. may require adjustments in your time/temp settings.*

Customer Support

For support on these or any of our products, please call our toll-free number for assistance: **877.795.1500**. You may also write to us at support@laserreproductions.com.